


General Description: A portable A.M./F.M. radio cassette recorder operating from mains or battery supplies. The internal battery is disconnected on inserting the mains plug. An integral microphone is fitted and automatic level operates on all inputs. Sockets are provided for the connection of auxiliaries and earphone.

Mains Supply: 240V, 50Hz.


Batteries: 9V (6 × HP2).

Wavebands: L.W. 145-260kHz; M.W. 520-1,620kHz; S.W. 5·8-16MHz; F.M. 87·5-104MHz.

Loudspeaker: 4Ω impedance.



(R330) DRIVE CORD - MODEL 'GOLF' RC1040



(R331c) CIRCUIT DIAGRAM (I.F. and A.F. STAGES) - MODEL 'GOLF' RC1040 (Continued)