

CRTS

ADDENDUM SHEET TO P.C.3 SERVICE MANUAL

TP432

Regentone RECORD PLAYER MODEL TP432



DIVISION OF **STC**

Issued MAY 1965

COMBINED RADIO AND TELEVISION SERVICE LTD

REGENT WORKS, SIDCUP, KENT. Tel: FO0tscray 3333

SERVICE ORGANISATION FOR KB · REGENTONE · R.G.D. · ACE · ARGOSY

ALSO PROVINCIAL DEPOT AT

COLLEGE MILTON

EAST KILBRIDE

GLASGOW

EAST KILBRIDE 25101

Dimensions :

Height —	8"
Width —	15 $\frac{3}{4}$ "
Depth —	17 $\frac{1}{2}$ "
Weight —	18 $\frac{1}{2}$ lbs.

DESCRIPTION	PART/LOCATION No.
Cabinet Assembly	1000/4/21742
Handle Assembly	28/114/2/14188
Moulded Foot (8 off)	28/121/1/21448
Catch (Brass)	28/108/14193
Strut Hinge (2 off)	28/127/21678
Rear Vent Moulding	28/115/1/13592
Lid Trim	28/123/13670
Lid Front Liner	35/301/1/21790
Front Trim	28/125/13741
Speaker Grille	28/113/13248
Hinge Platform (4 off)	35/315/2/14217
Motor Board	1000/4/51/21789
Cover Assembly Rvtd.	998/156/20008
Record Changer UA15	37/35/19751
Motor	37/35M/19621
P.U. Cartridge TC8M	TC8M/19257
78 Stylus TC8G	TC8G/19240
LP Stylus TC8R	TC8R/19232
Speaker (7" x 3 $\frac{1}{2}$ " Impedance 25 ohms)	11/159/03114
Neon (Red)	13/369/12247
Treble Control (Rim Edge) 500K Lin.	9/260/1/02226
Volume Control (Rim Edge) 5 Meg.	
Reverse Log.	9/251/02149
Bass Control (Rim Edge) 5 Meg.	
Reverse Log.	9/251/1/02098
On/Off Switch	13/82/1/10218

Chassis Removal Instructions

Remove chassis cover (2 screws). Remove motor board screws (4 off). Lift motor board clear complete with changer unit to give access to chassis. Remove the chassis by removing the two 4 BA nuts holding it to the baffle. The printed circuit may then be detached from the metalwork by removing the fixing screws (2 off) and the two screws securing the heat sinks.

N.B. Do not operate amplifier without heat sinks secured to the aluminium plate.